



415  
435  
512  
516  
532  
532/1  
532/2  
552  
882

Repair instructions


STAHLWILLE®

MADE IN CROENBERG  
MADE IN GERMANY

## FREQUENT USE




## INFREQUENT USE




## SPARE PARTS

|  |  |  |
|----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|
| 415                                                                              | 1/4"                                                                              | 19010000                                                                          |
| 435                                                                              | 3/8"                                                                              | 19020000                                                                          |
| 512 // 516 // 532 // 532/1 // 532/2                                              | 1/2"                                                                              | 19040000                                                                          |
| 552                                                                              | 3/4"                                                                              | 19050000                                                                          |
| 882                                                                              | 1"                                                                                | 19070000                                                                          |


1




2




3



4




5




6-12


## 6 CLEAN




7




8




9



10



11



| Nr.   | ■    | M <sub>A</sub> |
|-------|------|----------------|
| 415   | 1/4" | 28 + 2 cN·m    |
| 435   | 3/8" | 80 + 10 cN·m   |
| 512   | 1/2" | 125 + 10 cN·m  |
| 516   | 1/2" | 125 + 10 cN·m  |
| 532   | 1/2" | 125 + 10 cN·m  |
| 532/1 | 1/2" | 125 + 10 cN·m  |
| 532/2 | 1/2" | 125 + 10 cN·m  |
| 552   | 3/4" | 800 + 50 cN·m  |
| 882   | 1"   | 800 + 50 cN·m  |

TOOLS THAT  
... inspire

STAHLWILLE Eduard Wille GmbH & Co. KG  
Lindenallee 27 · 42349 Wuppertal · Germany  
Tel.: +49 202 4791-0 · Fax: +49 202 4791-200  
info@stahlwille.de · www.stahlwille.com



12

