



411
422
515
735/5
735/10
735/20
735/40
735/40HD




Repair instructions



FREQUENT USE



INFREQUENT USE




SPARE PARTS


411	1/4"	19200002
422 // 735/5	3/8"	59251105
735/10	1/2"	59251105
515 // 735/20	1/2"	59251120
735/40	3/4"	59251120
735/40HD	3/4"	59251165

19200003	19200001	10771 / T25
59251205	59251005	10771 / T30
59251205	59251010	10771 / T30
59251220	59251020	10771 / T30
59251240	59251040	10771 / T30
59251265	59251065	10771 / T40


1




2 CHECK



3




4 CLEAN OR REPLACE




5-10


5




6




7




8



9



10



TOOLS THAT
... inspire

STAHLWILLE Eduard Wille GmbH & Co. KG
Lindenallee 27 · 42349 Wuppertal · Germany
Tel.: +49 202 4791-0 · Fax: +49 202 4791-200
info@stahlwille.de · www.stahlwille.com

© STAHLWILLE Eduard Wille GmbH & Co. KG // 65/06/23 DHF // V 2.0 // 91979804



service.stahlwille.de

