




DIN EN 806
DIN EN 1717
DIN 1988

Global Standards

°C / °F

max. 70 °C / 158 °F

✓ 60 °C / 140 °F

min. 10 °C / 50 °F

✓ 3 bar / 43,5 psi

min. 1 bar / 14,5 psi

max. 10 bar / 145 psi

3 min.

max. 70 °C / 158 °F

www.kludi.com

- D

Montage- und Bedienanleitung

CN

安裝及操作指南

CZ

Návod k instalaci a k použití

E

Instrucciones de montaje y de manejo

F

Instructions de montage et mode d'emploi

GB

Installation and operating instructions

GR

ΟΔΗΓΙΕΣ ΕΓΚΑΤΑΣΤΑΣΗΣ ΚΑΙ ΣΥΝΤΗΡΗΣΗΣ

H

Szerelési és használati utasítás

I

Istruzioni di montaggio e per l'uso

NL

Montagehandleiding en Gebruiksaanwijzing

PL

Instrukcja montażu i obsługi

RO


Instrucțiuni de montaj și utilizare

RU

Руководство по монтажу и эксплуатации


SK

Návod na montáž a obsluhu




Kludi GmbH & Co. KG
Postfach 25 60
D-58685 Menden
Am Vogelsang 31-33
D-58706 Menden


Telefon: (D) +49 (0) 23 73 / 904-0
Telefax: (D) +49 (0) 23 73 / 904-4 65
E-Mail: info@kludi.de
Internet: www.kludi.com





2a.




3a.



1b.



2b.



3b.

