




4.

Diagram 4 illustrates the disassembly of the front wheel hub. The steps are numbered 12 through 16:

- 12:** Removal of the hub cap using a screwdriver.
- 13:** Removal of the hub nut using a wrench.
- 14:** Removal of the hub using a wrench.
- 15:** Removal of the hub washer.
- 16:** Removal of the hub nut.

A warning triangle is shown next to the hub cap, indicating a caution.

A diagram of a road layout. It starts with a triangular warning sign containing an exclamation mark. The road then enters a roundabout with three gears and a car icon. After the roundabout, the road splits into two lanes. A curved arrow points from the left lane to the right lane, with the number 17 above it.

18

19