









DIN EN 806
DIN EN 1717
DIN 1988
Global
Standards



- ⓓ Montage- und Bedienanleitung
- ⓐ 安装及操作指南
- Ⓒ Návod k instalaci a k použití
- Ⓔ Instrucciones de montaje y de manejo
- Ⓔ Paigaldamine ja kasutamine
- Ⓕ Instructions de montage et d'utilisation
- Ⓖ Installation and operating instructions
- Ⓖ ΟΔΗΓΙΕΣ ΕΓΚΑΤΑΣΤΑΣΗΣ ΚΑΙ ΣΥΝΤΗΡΗΣΗΣ
- Ⓕ Szerelési és használati utasítás
- Ⓘ Istruzioni di montaggio e per l'uso
- Ⓕ Montavimo ir naudojimo instrukcija
- Ⓕ Montāžas un lietošanas instrukcija
- Ⓖ Montagehandleiding en Gebruiksaanwijzing
- Ⓕ Instrukcja montażu i obsługi
- Ⓕ Instrucțiuni de montaj și utilizare
- Ⓕ Руководство по монтажу и эксплуатации
- Ⓕ Návod na montáž a obsluhu
- Ⓕ Navodila za montažo in uporabo
- Ⓕ Інструкція по монтажу та експлуатації
- Ⓕ تعليمات التركيب والتشغيل




Kludi GmbH & Co. KG
Postfach 25 60
D-58685 Menden
Am Vogelsang 31-33
D-58706 Menden

Telefon: (D) +49 (0) 23 73 / 904-0
Telefax: (D) +49 (0) 23 73 / 904-4 65
E-Mail: info@kludi.de
Internet: www.kludi.com

KLUDI

1.



2.

